





Twist AM




mm



A,B,C




A (mm)	B (mm)	C (mm)	D (mm)	Angle
155	720			
200	715			
250	705			
300	695			
350	678			
400	660			
450	639			
500	615			
550	585			
600	555			
650	525			
700	495			
750	465			
800	435			
850	405			
900	375			
950	345			
1000	315			



- 1
- 2
- 3
- 4

800mm



❖


❖ Dip 7 on




off



❖ Start 1 start 2

Dip 8 on
Dip 8 off

Dip 7







棕线是正极，蓝线是负极，绿线是信号线（不分正负极）

dip 7 on
 " 1" " 2" " 3"
 " START1" " START2" 1
 OPEN CLOSE LED

1			
2	START1" START2"		15
	" STATUS" led		
3			
❖	"		
❖	" START1"		
❖	" START1"	- -	
4			
❖	"		
❖	" START2"		
❖	" START2"	- -	